

Calsense 2-station(model CS-2W-2ST) Decoder Installation

Use 3M Scotchcast #3570G-N epoxy packs for **ALL** wire splices.

